


PUMP CONTROL PANEL BACK PANEL LAYOUT



PUMP CONTROL PANEL FRONT PANEL LAYOUT

NOTE: LIGHTNING ARRESTER IS TO BE LOCATED ON THE OUTSIDE OF ENCLOSURE